

Pro Fit™ Rechargeable Battery

Operation

Thanks for purchasing the Pro Fit™ with rechargeable batteries. We hope you will have years of trouble free operation so you can enjoy the enhanced hearing protection of Pro Fit™.

Following these few simple steps will keep your rechargeable batteries in optimum condition.

1. The Pro Fit will operate with either a rechargeable or non-rechargeable battery.
2. The rechargeable battery should provide approximately 12 hours of continuous operation. If used for shorter durations, please open the battery door to prevent the device from continuing to discharge.
3. ONLY put the Pro Fit™ into the portable recharging station with rechargeable batteries in the battery compartment. Placing the Pro Fit™ into the recharging station with non-rechargeable batteries may harm the Pro Fit™ and void your warranty.
4. Put the Pro Fit™ into the recharging station with the faceplate (side with the battery door) facing up. You should be able to see the light on your Pro Fit™ turn on when charging.
5. From complete discharge to full charge takes about six hours.
6. A new set of rechargeable batteries will be good for about 500 full charge cycles or two years, whichever comes first.